

CLEANERS



DISSOLVES COFFEE
RESIDUE QUICKLY



EASY AND QUICK
MAINTENANCE



SAFE FOR OPERATORS



CLEAN CAFF

DETERGENT FOR ESPRESSO COFFEE MAKER
FILTERS AND ARMS

pH 13

H.A.C.C.P.



Size	1000 ml
Pieces per box	6
Boxes per layer	20
Boxes per pallet	80
EAN Code	8007134824917

WHAT IT IS FOR

Special liquid detergent for cleaning espresso coffee maker filters and arms fast. Dissolves baked-on and burnt remnants of coffee grease instantly. Allows easy and quick maintenance. It is even effective on parts of the machine that hands or cleaning brushes cannot get to, and coffee aroma will not be affected by dirt and grease.

RECOMMENDED DOSAGE

Dispense 25 ml into the blind filter and open the dispenser for a few seconds. For washing immersed, use it diluted at 4%.

USE

To clean filters and arms: pour 20 ml of undiluted product into the blind filter, open the dispenser for a few seconds, close it and repeat the operation until you see clean water come out. Perform thorough rinsing. For cleaning moving parts: use the product diluted in boiling water by immersing the parts to be treated. Then rinse thoroughly.